



NEWLAND SCANNER: ADD a prefix "E" to the scanned code. Just for testcase only.



Restore All Factory Defaults



Enter Setup

Set custom prefix



Save



Enable Prefix



**** Exit Setup**