

NEWLAND SCANNER: ADD a suffix "F" to the scanned code. Just for testcase only.



Restore All Factory Defaults



Enter Setup

Set custom suffix





1



6



Save

Enable suffix





** Exit Setup